

Fuses - 1ea 5A & 15A

Burner Shield

Overheat
Thermo
Switch

Aux.
Connection
Plug


Remote
Socket

Panel
Harness
Socket

Main PCB

Combustion Fan

Exhaust Outlet



Combustion Fan

Fuel Connection Elbow

Exhaust Outlet

D.C. Power Socket

Lid Jumper

Fuel Pipe

Fuel Pump

**Glow
Plug**

Thermocouple

